

NOROX[®] PULCAT AW

DESCRIPTION

Norox[®] Pulcat AW is a proprietary peroxide solution in phlegmatizer primarily used for cure initiation of unsaturated polyester and vinyl ester resins in the pultrusion process. Norox[®] Pulcat AW can also be used in cobalt promoted resins for ambient temperature cures.

TYPICAL PROPERTIES

Active Oxygen	8.7 - 9.0 %
Form	Liquid
Color	Colorless
Specific Gravity @ 25°C	1.0
Viscosity, cps @ 25°C	14.5
Flash Point (C.O.C.), min.	60°C
Solubility	Immiscible w/water Soluble in phthalate

APPLICATION

Norox[®] Pulcat AW demonstrates a high level of reactivity at elevated temperatures in the range of 60°C – 150°C, without the use of accelerators. When used in the pultrusion process, a lower reactivity peroxide such as Norox[®] TBPB must be included to provide a good final cure. A suggested starting point formulation would include 1.5 phr Norox Pulcat AW and 1.0 phr Norox[®] TBPB. Norox[®] Pulcat AW can also be used for the production of flat and corrugated sheet when discoloration by cobalt accelerators is not tolerable. The pot-life of Norox[®] Pulcat AW in unpromoted resin at 20°C has been observed to be 10 hours.

NOROX[®] PULCAT AW

STORAGE

- Storage at 80°F or below is recommended. Storage below 70°F is recommended for maximum shelf life.
- Store in original containers **away** from flammables and all sources of heat, sparks, or flames; out of direct sunlight; and **away** from **cobalt naphthenate**, other promoters, accelerators, oxidizing or reducing agents and strong acids or bases.
- **Leaking containers** – Remove and isolate in a safe area. Re-package or dispose immediately (see **spills**).
- **Never** store in refrigerators containing food and/or beverages.
- Consult National Fire Protection Association (NFPA) Code 432 and/or local regulatory agencies.
- Rotate stock, use oldest date first.

HANDLING

- Inform all personnel of procedures for safe handling and review MSDS with them.
- Remove from storage area only the amount needed for one shift.
- Wear safety glasses or goggles and chemical resistant gloves.
- Keep away from heat, flames, and sparks.
- Avoid breathing vapors.
- Dilution is not recommended. Never dilute with acetone.
- **Never** add peroxides directly to promoters or vice-versa, violent decomposition can occur.
- Prevent contamination such as contact with dust, over spray, wood, and combustible material.
- Avoid contact with materials other than polyethylene, polypropylene, Teflon®, Tygon®, or similar materials, glass or glass-lined steel, and 304 or 316 stainless steel or equivalent.

FIRST AID

- EYES – Flush immediately with large amounts of fresh water and continue washing for at least 15 minutes. **Medical attention is needed.**
- SKIN – Wash with soap and water.
- INGESTION – Administer large amounts of milk or water and call a physician immediately. Do not induce vomiting. As an aid to the physician, suggest calling your local Poison Control Center.

SPILLS

- Clean up immediately by absorbing with inert material – vermiculite or sand.
- After absorbing, moderately wet immediately with water and place in a clean plastic bag inside a plastic pail.
- Dispose of immediately in accordance with local, state, and federal regulations.
NOTE: Spilled peroxides, if not immediately cleaned up, can become contaminated and ignite or decompose in a hazardous, violent manner.

FIRE

- Peroxides ignite readily and burn vigorously with acceleration.
- Use water from a safe distance – preferably with a water-fog nozzle.
- For very small fires, an extinguisher with carbon dioxide, foam, or dry chemical may be effective.
- In case of fire in or near a storage area, cool stored containers with water spray.

PACKAGING, SHIPPING & AVAILABILITY

- The standard package sizes of Norox[®] Pulcat AW are cases of 4x8 lb. and 4x4 kg polyethylene bottles; and 40 lb. or 20 kg Hedpacks. For custom package sizes, please contact your local distributor or Syrgis Performance Initiators, Inc.
- Classification – Please refer to the specific Norox[®] Pulcat AW Material Safety Data Sheet under section 14, Shipping Description.
- Norox[®] Pulcat AW is available through a nation-wide distributor network. Call Syrgis Performance Initiators, Inc. for the name of the distributor in your area.

NOTE: MSDS's for all our products may be requested thru the website www.syrgisperformanceinitiators.com

"The information contained in this bulletin is based on information received of our staff and of others and is presented in good faith and with every belief in its accuracy. Due to the extensive technology involved in its usage, the manufacturer in no way guarantees such information, nor does he make any recommendations as to its use in the infringement of any patent. The information contained in this bulletin supersedes and replaces all information contained in all previous bulletins. Seller makes no warranty of any kind, expressed or implied, except that the goods sold hereunder shall meet the specifications of the buyer. After goods are accepted by the buyer within the time specified the buyer assumes all risk and liability for damages resulting from the use of the goods. Whether used by the buyer singly or in combination with other products, or if sold by buyer to third persons either in its original form or if repackaged by buyer and then sold to third persons."



SYRGIS PERFORMANCE INITIATORS, INC.

334 Phillips 311 Road, Helena Arkansas 72342

Tel. (800) 786-6722 • Fax (800) 987-0845 • www.syrgis.com